




Wild West Stage Coach
Item No. MMS189




It is highly recommended that you visit
www.metal-earth.com/360/mms189
to see the completed model before assembling your own

Metal sheets

Parts that are in the same color are duplicates



In order to avoid possible injury from sharp edges, please carefully discard the metal sheets after parts have been removed



Legends:

- E** Engraved / Color side
- NE** Non-engraved / Silver side
- Attention point
- Insert tab and bend 90 degrees
- Insert tab and twist 90 degrees

Assembly tip:

If needed, slightly twist tabs to hold parts together then untwist and bend them down for a nice finish

Recommended tools:


-Wire cutters: helpful for taking parts from the metal sheets.






-Tweezers or needle nose pliers: helpful for folding parts, bending and twisting tabs.





Assembly Flow Chart





Make sure part **B-16** are connected to the right holes on part **B-17** and **B-18** as shown below.



Insert the tabs in the holes but do not bend or twist them.

